EXHIBIT 2






Digital Audio Server

MCX-1000

OWNER'S MANUAL



GOOG-SONOSITC-PA-00022492

UCGBA

Controlling MusicCAST clients

Editing MusicCAST client names

Edit the names of the MusicCAST clients you are using in your MusicCAST system. This function is useful as allows you to for example, assign names to client MusicCAST clients based on their location.

1 Carry out the procedure described on page 92 to display the Client Playback screen.



- 2 Use ∧/~ to move the cursor to select a MusicCAST client.
- 3 Press SUB MENU. The Sub Menu appears on the on-screen display.



4 Use \(\setminus \) to move the cursor to "Edit name" and press SELECT.

The on-screen keyboard appears on the on-screen display.

5 Use the on-screen keyboard (or a PS/2 keyboard if you have one connected) to enter a new name for your MusicCAST client.

See page 78 for an explanation of how to enter characters using the on-screen keyboard.

6 When you have finish entering the new MusicCAST client name, use ✓/⟨✓/⟩ to move the cursor to "OK" and press SELECT to confirm the new name and close the Sub Menu. Select "Cancel" to close the Sub Menu without changing the name.





This document is printed on chlorine free (ECF) paper with soy ink.

YAMAHA ELECTRONICS CORPORATION, USA 6660 ORANGETHORPE AVE., BUENA PARK, CALIF. 90620. U.S.A.
YAMAHA CANADA MUSIC LTD. 135 MILNER AVE., SCARBOROUGH, ONTARIO M1S 381, CANADA
YAMAHA ELECTRONIK EUROPA G.M.D.H. SIEMENSSTR. 22-34, 25462 RELLINGEN BEI HAMBUHG, F.R. OF GERMANY
YAMAHA ELECTRONIQUE FRANCE S.A. RUE AMBROISE CROIZAT BP70 CROISSY-BEAUBOURG 77312 MARNE-LA-VALLEE CEDEX02, FRANCE
YAMAHA ELECTRONICS (UK) LTD. YAMAHA HOUSE, 200 RICKMANSWORTH ROAD WATFORD, HERTS WD18 730, ENGLAND
YAMAHA SCANDINAVIA A.B. J A WETTERGRENS GATA 1, BOX 30053, 400 43 VÄSTRA FRÖLUNDA, SWEDEN
YAMAHA MUSIC AUSTRALIA PTY, LTD. 17-38 MARKET ST., SOUTH MELBOURNE, 3205 VIC., AUSTRALIA

YAMAHA CORPORATION
Printed in Japan WB18700-2